
# DEEBOT X1 S OmniCyclone Care Kit

# Quick Start Guide


## Product Introduction



DEEBOT



OMNI Station



Base



Instruction Manual



Power Cord



Corner Guards



ECOVACS DEEBOT
Heavy-duty
Cleaning Solution



ECOVACS DEEBOT
Cleaning Solution

These are spare parts: Side Brush*2; Main Brush*1; Antibacterial Filter*3

Tip: It is recommended to retain all original packaging materials after receiving your product to ensure smooth after-sales support in the event of transportation damage.
The actual appearance is subject to the actual product.


## IMPORTANT SAFETY INSTRUCTIONS

- Be careful of hot water burns. Do not touch the water outlet of the OMNI Station or remove DEEBOT while it's washing the mop in the station.
- If there are hard objects or small particle toys on the floor, avoid using DEEBOT to clean to prevent damage.
- If there is ponding or sticky objects on the floor, avoid using DEEBOT to clean to prevent liquid immersion.
- Do not use any liquid to rinse DEEBOT and OMNI Station.
- For the first use, it is recommended to map your home first and repeat vacuuming for 2-3 times before mopping for better cleaning performance.
- Please clean the dust container and filter regularly.
- Please clean the mop washing tray regularly.
- Please clean the driving wheels regularly.
- Please use ECOVACS's official cleaning solution.


Learn more at www.ecovacs.com

## Product Guide—Station Setup

**1** Remove all protective materials from the OMNI station.




**2** Install the base until you hear a "click" sound, indicating the 4 slots are securely aligned.





Note:
A thoughtful pair of corner guards is included to enhance user safety and improve handling comfort.
To install: Align the inner slot of the corner guard with the edge and press it into place. Compatible with all DEEBOT corner designs.

**3** Place the station on a level, hard surface against a wall, then power it on.





Note:
It's recommended to place the station at a place with strong Wi-Fi signals.
Recommended placement: 0.8m in front and 0.05m to the sides.
A slight mechanical sound from the bottom of the station indicates the station is powered on.

**4** Open the clean water tank and fill it. After filling, place the tank back into the station.




Note:
The water inside the tank may appear as water stains due to the function test. It is safe to use.
Do not add hot water, as it may cause deformation.


**5** Take off the cleaning solution tank's cover, pull out the two cleaning solution boxes, and place them on a level, hard surface.
Pour the ECOVACS DEEBOT cleaning solution into the blue box and the heavy-duty cleaning solution into the black box. After securing the box lids, push them back into the station and close the tank's cover. Return the cleaning solution tank's cover and press the cover firmly to secure it in position.



Note:
For better performance and longer lifespan of the product, please use ECOVACS DEEBOT cleaning solution.
Do not overfill with cleaning solution, as it may overflow when the lid is secured.
If you do not use floor cleaning solution regularly, this step can be skipped and the Auto Cleaning Solution Dispense function can be disabled in the App.

## Product Guide—App Connection

**1** Remove all protective materials from DEEBOT.




**2** Search for "ECOVACS HOME" in the app store or scan the QR code below to install the ECOVACS HOME App.


Download on the App Store
Get it on Google Play
ECOVACS HOME

Note:
Wi-Fi only supports the 2.4 GHz band and currently does not support the 5 GHz band.

**3** Open the ECOVACS HOME App and sign up with your e-mail address.






**4** Detach the top cover and use ECOVACS HOME APP to scan the QR code on DEEBOT. Follow the instructions to complete the network connection.




Note:
DEEBOT uses Bluetooth by default for network setup, please ensure that Bluetooth is enabled on your phone.
Open the ECOVACS HOME APP,search for your DEEBOT, and follow the instructions to complete the setup.

**5** Move DEEBOT back to the station. The voice prompt "Start charging" and a breathing white light indicate a successful docking and charging in progress. Start using DEEBOT after creating a map in the ECOVACS HOME APP or via voice commands.






Note:
For the first use, once quick mapping is complete, fully charge DEEBOT before initiating cleaning for the first time.
Please start vacuuming for 2-3 times before starting mopping for better cleaning performance.
For more voice features, go to the ECOVACS HOME App.